



Commercial Mower Canopies

Part Numbers

Bush Hog Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
<i>*M2355, M2561, M2675</i>	(1)	*BHZT2A	*BHZTAL	NA	NA	NA
<i>Femco Rops # 3646: PZ3061, PZ3072, PZ3561</i>	(2)	C2A5032	CA5032	BA6006	UC2A11	UCA11
<i>Rops # 3646:</i>	(3)	C2A5032	CA5032	BA2002		

*Price \$265

Dixon Model Number	Custom Fit Canopies Part Numbers		Universal Canopies Part Numbers (Brackets included)
	G R P	Diamond Tread Aluminum	Bracket Assembly
<i>Models with Full Vision Rops 2075:</i>	(1)	CA5834	BA3009 UCA11

eXmark Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
<i>Models: ALL - Lazer Z's, Front Runner, & Ultra Vac Pioneer series with rear leaning ROPS</i>	(1)	C2A5032	CA5032	BA1003	UC2A11	UCA11



Part Numbers (Cont.)

Ferris Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
<i>Models:</i> IS3100Z	(1)	C2A5032	CA5032	BA6006	NA	NA
<i>Models:</i> IS4500Z	(2)	C2A5032	CA5032	BA2002	UC2A11	UCA11
<i>Models:</i> S200Z, IS1500Z, IS1500ZX, IS2000Z, IS2500Z	(3)	C2A5031	CA5031	BA1014	NA	NA

Grasshopper Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	G R P	Tan	Diamond Tread Aluminum	Bracket Assembly	Tan	Diamond Tread Aluminum
<i>Models using ROPS # 3631 & 3632:</i> 200, 300, 400, 700 & 900 Series	(1)	C15027	CA5027	BA7009	UC111	UCA11



Part Numbers (Cont.)

Hustler Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)
	G R P	Diamond Tread Aluminum	Bracket Assembly	Diamond Tread Aluminum
<i>Model # 27707020: Super Z Diesel*</i> <i>Models using Femco ROPS # 3814: Z4</i>	(1)	CA5032	BA7003	UCA11
<i>Model: Super Z Gas*</i>	(2)	CA5039	BA7003	
<i>Model: Mini Z *</i>	(3)	CA5035	BA1003	NA
<i>Model: MZ</i>	(4)	CA5041	BA7003	
<i>Models using Femco ROPS # 3834: X one*</i>	(5)	CA5032	BA1002	NA
<i>Models using Femco ROPS # 3835: Diesel Z*</i>	(6)	CA5032	BA7003	NA
<i>Models using Femco ROPS # 3778: Z & Super Z*</i>	(7)	CA5041	BA3009	UCA11
<i>Models using Femco ROPS # 3819: R Series, Fast Trak, Fast Trak Super Duty</i>	(8)	CA5031	BA3009	UCA11
<i>104</i>	(9)	CA5034	BA1014	
<i>Narrow ROPS ~23"</i>	(9)	CA5024	BA1003	NA

* must identify ROPS width

Husqvarna Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	NA	Diamond Tread Aluminum	Bracket Assembly	NA	Diamond Tread Aluminum
<i>Femco ROPS # 3620</i>	(1)		CA5034	BA3009		UCA11
<i>Rops # 522676801: PZ5426, PZT234, PZ6029 (20deg L 12 deg T)</i>	(2)		CA5032	BA3013		



Part Numbers (Cont.)

Jacobsen Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>GRP</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>
HR9016 – Full Vision ROPS # 113-07120	(1)	Not Available – Order Universal Canopy			UC311	UCA11
HR4600	(2)					
TRI-King 1900D	(3)					
HR5111	(4)					

John Deere Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>GRP</i>	<i>Green</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Green</i>	<i>Diamond Tread Aluminum</i>
F911, F925, F932, F935, F1145, 3215, 3225	(1)	C55031	CA5031	BA6103	UC511	UCA11
1600 Series	(2)	C55037	CA5037	BA3002		
Z TRAK: 737, 757, 777	(3)	C55029	CA5029	BA1002		
Z TRAK: 727, 717, 520A	(4)	C55031	CA5031	BA1013		
*Z Trak: 997 (Dog Leg rops) – NEED ROPS WIDTH	(5)	C55839	CA5839	BA6011	NA	NA
*Z Trak: 997	(6)	C55835	CA5835	BA3009	UC501	UCA01
All Z500, Z800 Series, ZTRAK 700 Series: Z710, Z720 and ZTRAK 900* Z920a	(7)	C55031	CA5031	BA6010	NA	NA
1600 Series:	(8)	C55037	CA5037	BA3002	UC511	UCA11
ZTRAK 900 Series: New ROPS* Z920m, Z930m Z915b, Z994r	(9)	C55031	CA5031	BA6013	NA	NA
ZTRAK: 997R (until 2019)	(10)	C55035	CA5035	BA6013	NA	NA
ZTRAK: 997R (2020 forward)	(10)	C55035	CA5035	BA6015	NA	NA
1550, 1580	(11)	C55035	CA5035	BA1003	NA	NA
720e Vertical ROPS	(12)	C55031	CA5031	BA3009	UC511	UCA11

*Caution! 2 Different rops – must identify rops style



Part Numbers (Cont.)

Kubota Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>
<i>Models using ROPS # SFZD-F28:</i> ZD18, ZD21, ZD28	(1)	C35039	CA5039	BA3001	UC311	UCA11
ZG20F, ZG23F, ZD221, ZG222, ZG227, ZD220, ZD1011, ZD1021	(2)	C35034	CA5034	BA3002		
<i>Models Using ROPS # SFZD - F31:</i> ZD321, ZD326, ZD331, ZD323, ZG327, ZD1211*	(6)	C35037	CA5037	BA2002		
<i>Models using ROPS # SFGF-18A:</i> GF1800E, GF1800D	(3)	C35027	CA5027	BA2004		
<i>Models using ROPS # SFF-24:</i> F2000, F2100, F2100E, F2400	(4)	C35034	CA5034	BA3005		
<i>Models using ROPS # SFF-30:</i> F2260, F2560, F2560E, F3060 F2880, F3680, F2680, F2690	(5) (7)	C35031 C35839	CA5031 CA5839	BA6003 BA2002		
Z100 Kommander Series: Z121S, Z122E, Z125E	(8)	C35025	CA5025	BA3002	UC301	UCA01
Z700 Series	(9)	C35032	CA5032	BA7003	UC311	UCA11
Z421	(10)	C35029	CA5029	BA1014	NA	NA

***Verify this top will work with universal**

Landpride Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>		<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>		<i>Diamond Tread Aluminum</i>
<i>Models using ROPS # 3810:</i> Z48, Z54, ZSR54, ZSR60 <i>Models using ROPS # 3137:</i> ZT60, ZT72, ZT721	(1)		CA5032	BA7003		UCA11



Commercial Mower Canopies

Massey Ferguson Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
ZT29, ZT33	(1)	C25039	CA5039	BA2002	UC211	UCA11

New Holland Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	New Holland Blue	Diamond Tread Aluminum	Bracket Assembly	New Holland Blue	Diamond Tread Aluminum
<i>CM Models:</i> CM222, CM224, CM272, CM274	(1)	C6A5032	CA5032	BA1003	UC6A11	UCA11
<i>MC Models:</i> MC22, MC27, MC28, MC35	(2)	C6A5034	CA5034	BA1003		
<i>TZ Models:</i> TZ18DA, TZ24DA	(3)	C6A5031	CA5031	BA6006		

Scag Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	Orange	Diamond Tread Aluminum	Bracket Assembly	Orange	Diamond Tread Aluminum
<i>*Model SCZ (Cheetah) with Femco ROPS # 3499</i>	(1)	C3A5027	CA5027	BA3003	UC3A11	UCA11
<i>*Model STT (Turf Tiger) with Femco ROPS # 3457 or # 3467</i>	(2)	C3A5035	CA5035	BA3003		
<i>Model STC/STWC (Tiger Cat/Wild Cat) with Femco ROPS # 3496, 3721, 3772</i>	(3)	C3A5034	CA5034	BA3009		
<i>*Model STT (Turf Tiger) with Femco ROPS # 3685</i>	(4)	C3A5034	CA5034	BA3003		
<i>Model SFZ (Freedom Z) with Femco ROPS # 3726</i>	(5)	C3A5027	CA5027	BA7003		



*Model SCZ (Cheetah) with Femco ROPS # 3830	(6)	C3A5029	CA5029	BA2002		
*Model STT (Turf Tiger) with Femco ROPS # 3722	(7)	C3A5034	CA5034	BA2002		

*Must order by ROPS #

Part Numbers (Cont.)

Snapper Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>
<i>PRO</i>	(1)	C25031	CA5031	BA7003	UC211	UCA11
<i>Snapper Pro S150</i>	(2)	C25031	CA5031	BA6010	NA	NA

Toro Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>
<i>Z Master: Z200 & Z 500 Series Midmount ZRTS Z100 & Z 400 Series Midmount ZRTS</i>	(1)	C2A5032	CA5032	BA1003	UC2A11	UCA11

Yazoo/Kees Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>
<i>ROPS # Femco 3620:</i>	(1)	C2A5034	CA5034	BA3009	UC2A11	UCA11