



Commercial Mower Canopies

Part Numbers

Altoz Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)
	G R P	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Diamond Tread Aluminum</i>
<i>TRX 561</i>		CA5027	BA6016	NA

Bush Hog Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	G R P	<i>Red</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>
<i>*M2355, M2561, M2675</i>		*BHZT2A	*BHZTAL	NA	UMC-CSR	UMC-ALUM
<i>Femco Rops # 3646: PZ3061, PZ3072, PZ3561</i>		C2A5032	CA5032	BA6006	UMC-CSR	UMC-ALUM
<i>Rops # 3646:</i>		C2A5032	CA5032	BA2002		
<i>HDZ3173</i>		CA5037	BA9003	BA9003	UMC-CSR	UMC-ALUM

Cub Cadet Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)
	G R P	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Diamond Tread Aluminum</i>
<i>Pro Z 900</i>		CA5025	BA7009	UMC-ALUM



Part Numbers (Cont.)

eXmark Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
<i>Models: ALL - Lazer Z's, Front Runner, & Ultra Vac Pioneer series with rear leaning ROPS</i>	(1)	C2A5032	CA5032	BA1003	UMC-CSR	UMC-ALUM

Ferris Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
<i>Models: IS3100Z</i>	(1)	C2A5032	CA5032	BA6006	NA	UMC-ALUM
<i>Models: IS4500Z</i>	(2)	C2A5032	CA5032	BA2002	NA	UMC-ALUM
<i>Models: S200Z, IS1500Z, IS1500ZX, IS2000Z, IS2500Z</i>	(3)	C2A5031	CA5031	BA1014	NA	UMC-ALUM

Grasshopper Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	G R P	Tan	Diamond Tread Aluminum	Bracket Assembly	Tan	Diamond Tread Aluminum



<i>Models using ROPS # 3631 & 3632:</i> 200, 300, 400, 700 & 900 Series	(1)	C15027	CA5027	BA7009	NA	UMC-ALUM
---	-----	--------	--------	--------	----	----------

Part Numbers (Cont.)

Hustler Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)
	G R P	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Diamond Tread Aluminum</i>
<i>Model # 27707020:</i> Super Z Diesel* <i>Models using Femco ROPS # 3814:</i> Z4	(1)	CA5032	BA7003	UMC-ALUM
<i>Model:</i> Super Z Gas*	(2)	CA5039	BA7003	
<i>Model:</i> Mini Z *	(3)	CA5035	BA1003	UMC-ALUM
<i>Model:</i> MZ	(4)	CA5041	BA7003	UMC-ALUM
<i>Models using Femco ROPS # 3834:</i> X one*	(5)	CA5032	BA1002	UMC-ALUM
<i>Models using Femco ROPS # 3835:</i> Diesel Z*	(6)	CA5032	BA7003	UMC-ALUM
<i>Models using Femco ROPS # 3778:</i> Z & Super Z*	(7)	CA5041	BA3009	UMC-ALUM
<i>Models using Femco ROPS # 3819:</i> R Series, Fast Trak, Fast Trak Super Duty	(8)	CA5031	BA3009	UMC-ALUM
104	(9)	CA5034	BA1014	UMC-ALUM
<i>Narrow ROPS ~23"</i>	(9)	CA5024	BA1003	UMC-ALUM

* must identify ROPS width

Husqvarna Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	NA	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	NA	<i>Diamond Tread Aluminum</i>
<i>Femco ROPS # 3620</i>	(1)		CA5034	BA3009		UMC-ALUM
<i>Rops # 522676801:</i> PZ5426, PZT234, PZ6029 (20deg L 12 deg T)	(2)		CA5032	BA3013		UMC-ALUM



Part Numbers (Cont.)

Jacobsen Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>
HR9016 – Full Vision ROPS # 113-07120	(1)	Not Available – Order Universal Canopy			UMC-KBO	UMC-ALUM
HR4600	(2)					
TRI-King 1900D	(3)					
HR5111	(4)					

John Deere Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Green</i>	<i>Diamond Tread Alum</i>	<i>Bracket Assembly</i>	<i>Green</i>	<i>Diamond Tread Aluminum</i>
F911, F925, F932, F935, F1145, 3215, 3225	(1)	C55031	CA5031	BA6103	UMC-JDG	UMC-ALUM
1600 Series	(2)	C55037	CA5037	BA3002		
Z TRAK: 737, 757, 777	(3)	C55029	CA5029	BA1002		
Z TRAK: 727, 717, 520A	(4)	C55031	CA5031	BA1013	UMC-JDG	UMC-ALUM
*Z Trak: 997 (Dog Leg rops) – NEED ROPS WIDTH	(5)	C55839	CA5839	BA6011		
*Z Trak: 997	(6)	C55835	CA5835	BA3009	UC501	UCA01
All Z500, Z800 Series, ZTRAK 700 Series: Z710, Z720 and ZTRAK 900* Z920a	(7)	C55031	CA5031	BA6010	UMC-JDG	UMC-ALUM
1600 Series:	(8)	C55037	CA5037	BA3002	UMC-JDG	UMC-ALUM
ZTRAK Z920M, Z930M (until 2019) Z950M, Z915B, Z994R(until 2019)	(9)	C55031	CA5031	BA6013	UMC-JDG	UMC-ALUM
ZTRAK Z994R (2020 forward)	(9)	C55031	CA5031	BA6015	UMC-JDG	UMC-ALUM
ZTRAK: 997R (until 2019)	(10)	C55035	CA5035	BA6013	UMC-JDG	UMC-ALUM
ZTRAK: 997R, Z920M, Z930M (2020 forward)	(10)	C55035	CA5035	BA6015	UMC-JDG	UMC-ALUM
1550, 1580	(11)	C55035	CA5035	BA1003	UMC-JDG	UMC-ALUM
720e Vertical ROPS	(12)	C55031	CA5031	BA3009	UMC-JDG	UMC-ALUM

*Caution! 2 Different rops – must identify rops style



Commercial Mower Canopies

Part Numbers (Cont.)

Kubota Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>	<i>Orange</i>	<i>Diamond Tread Aluminum</i>
<i>Models using ROPS # SFZD-F28:</i> ZD18, ZD21, ZD28	(1)	C35039	CA5039	BA3001	UMC-KBO	UMC-ALUM
ZG20F, ZG23F, ZD221, ZG222, ZG227, ZD220, ZD1011, ZD1021	(2)	C35034	CA5034	BA3002		
<i>Models Using ROPS # SFZD - F31:</i> ZD321, ZD326, ZD331, ZD323, ZG327, ZD1211*	(6)	C35037	CA5037	BA2002		
<i>Models using ROPS # SFGF-18A:</i> GF1800E, GF1800D	(3)	C35027	CA5027	BA2004		
<i>Models using ROPS # SFF-24:</i> F2000, F2100, F2100E, F2400	(4)	C35034	CA5034	BA3005		
<i>Models using ROPS # SFF-30:</i> F2260, F2560, F2560E, F3060	(5)	C35031	CA5031	BA6003		
F2880, F3680, F2680, F2690	(7)	C35839	CA5839	BA2002	UC301	UCA01
Z100 Kommander Series: Z121S, Z122E, Z125E	(8)	C35025	CA5025	BA3002	UMC-KBO	UMC-ALUM
Z700 Series	(9)	C35032	CA5032	BA7003	UMC-KBO	UMC-ALUM
Z421	(10)	C35029	CA5029	BA1014	UMC-KBO	UMC-ALUM

***Verify this top will work with universal**

Landpride Model Number	Custom Fit Canopies Part Numbers				Universal Canopies Part Numbers (Brackets included)	
	<i>G R P</i>		<i>Diamond Tread Aluminum</i>	<i>Bracket Assembly</i>		<i>Diamond Tread Aluminum</i>
<i>Models using ROPS # 3810:</i> Z48, Z54, ZSR54, ZSR60 <i>Models using ROPS # 3137:</i> ZT60, ZT72, ZT721	(1)		CA5032	BA7003		UMC-ALUM



Commercial Mower Canopies

Part Numbers (Cont.)

Massey Ferguson Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	Red	Diamond Tread Aluminum	Bracket Assembly	Red	Diamond Tread Aluminum
ZT29, ZT33	(1)	C25039	CA5039	BA2002	UMC-MFR	UMC-ALUM

New Holland Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	New Holland Blue	Diamond Tread Aluminum	Bracket Assembly	New Holland Blue	Diamond Tread Aluminum
<i>CM Models:</i> CM222, CM224, CM272, CM274	(1)	C6A5032	CA5032	BA1003	UMC-NHB	UMC-ALUM
<i>MC Models:</i> MC22, MC27, MC28, MC35	(2)	C6A5034	CA5034	BA1003		
<i>TZ Models:</i> TZ18DA, TZ24DA	(3)	C6A5031	CA5031	BA6006		

Scag Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	G R P	Orange	Diamond Tread Alum	Bracket Assembly	Orange	Diamond Tread Aluminum
<i>Model SCZ (Cheetah) with Femco ROPS # 3499</i>	(1)	C3A5027	CA5027	BA3003	UMC-SCG	UMC-ALUM
<i>Model STT (Turf Tiger) with Femco ROPS # 3457 or # 3467</i>	(2)	C3A5035	CA5035	BA3003		
<i>Model STC/STWC (Tiger Cat/Wild Cat) with Femco ROPS # 3496, 3721, 3772</i>	(3)	C3A5034	CA5034	BA3009		
<i>Model STT (Turf Tiger) with Femco ROPS # 3685</i>	(4)	C3A5034	CA5034	BA3003		
<i>Model SFZ (Freedom Z) with Femco ROPS # 3726</i>	(5)	C3A5027	CA5027	BA7003		
<i>Model SCZ (Cheetah) with Femco ROPS # 3830</i>	(6)	C3A5029	CA5029	BA2002		
<i>Model STT (Turf Tiger) with Femco ROPS # 3722</i>	(7)	C3A5034	CA5034	BA2002		



Commercial Mower Canopies

Part Numbers (Cont.)

Snapper Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	<i>G R P</i>	<i>Red</i>	<i>Diamond Tread Alum</i>	<i>Bracket Assembly</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>
<i>PRO</i>	(1)	C25031	CA5031	BA7003	UMC-MFR	UMC-ALUM
<i>Snapper Pro S150</i>	(2)	C25031	CA5031	BA6010	UMC-MFR	UMC-ALUM

Spartan Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	<i>G R P</i>	<i>Black</i>	<i>Diamond Tread Alum</i>	<i>Bracket Assembly</i>	<i>Black</i>	<i>Diamond Tread Aluminum</i>
<i>RZ Series: HD, PRO, RZ, RZ-C</i>		C15032	CA5032	BA1014	UMC-BLK	UMC-ALUM
<i>RT Series: HD, PRO</i>		C15032	CA5032	BA1014	UMC-BLK	UMC-ALUM
<i>SRT Series: XD, XDe</i>		C15032	CA5032	BA1014	UMC-BLK	UMC-ALUM
<i>KGZ Series: KGZ-XD</i>		C15032	CA5032	BA1014	UMC-BLK	UMC-ALUM

Toro Model Number	Custom Fit Canopies Part Numbers			Universal Canopies Part Numbers (Brackets included)		
	<i>G R P</i>	<i>Red</i>	<i>Diamond Tread Alum</i>	<i>Bracket Assembly</i>	<i>Red</i>	<i>Diamond Tread Aluminum</i>
<i>Z Master: Z200 & Z 500 Series Midmount ZRTS Z100 & Z 400 Series Midmount ZRTS</i>	(1)	C2A5032	CA5032	BA1003	UMC-CSR	UMC-ALUM